





A	Umbrella		1PC
B	Cap		1PC
C	Tube		1PC
D	Screw		1PC
E	Nut		1PC
F	Wrench		1PC
G	Screw		4PCS
H	Washer		4PCS
I	Wrench		1PC
J	Cross base A		1PC
K	Cross base B		1PC

Disassembly instruction




STEP 1

Press the spring, pull out the woven tape from the rib end. Remove the cap.




STEP 2

Unscrew the tube and cross base and separate them.




STEP 3

Remove the pin in shape "R" and separate the ribs.




STEP 4

Rotate and lift the long rib and remove the rib from the groove.



STEP 5

Turn the middle ribs downward to the groove, and separate the runner and ribs.



STEP 6

Flat the short ribs and remove the runner handle.

STEP 7

Turn the short ribs downward to the groove, and separate the ribs.

